Instruction Book

for

Morse Relay Keying Unit

Model MRK-1

Table of Contents

Section I Section III Section IV Section V Description
Theory of Operation
Installation
Operation
Parts List

Section I

Description

The Morse Relay Keying Unit, Model MRK-1, is designed specifically for use with the TMC Autohead Drive, Model AHD. When properly connected and adjusted, it will key a tone oscillator or other circuit in accordance with the dots and dashes perforated in the tape at any speed up to approximately 200 words per minute.

Reference Data

(a) Input: Three contact connector

(b) Output: Relay contacts

(c) Controls (top chassis): 1. Speed Control
2. Waveform Adjuster

(d) Input Power Requirements: 110 volts, appr. 10 watts

(e) Mounting: Spacings for AMD Cover

(f) Weight: Appr. 3 lbs.

Vacuum Tube Complement

Table 1-1

Symbol Type Ci Vl 117N7GT Rectifi

Circuit
Rectifier and Control Tube

Section II

Theory of Operation

The rectifier section of the 117N7GT serves to provide positive and negative voltages for the control section of the tube. When used in conjuction with an Autohead Drive, a negative voltage is supplied to one section of the keying fingers and a short circuit to the other section of the keying fingers. In operation, a negative pulse charges C3a and C3b, driving V1b to cut-off and thus opening the relay contacts. During the "ON" position of the code the grid of the control section is returned to the cathode potential, causing the relay contacts to close.

Section III

Installation

To install the Model MRK-1 Relay, proceed as follows:

1. Loosen the rear thumb screws on the AHD Cover.

2. Place the relay unit on tope of the AHD Cover, and slide the lugs under the thumb screws and tighten the screws.

3. Insert one end of the short special cable into the three hole socket in the AHD and the other end into a similar socket in the back of the relay unit.

4. Insert the line cord into relay unit and connect to 110 volt AC supply.


5. Connect the relay output (E1) to the TMC-Model RAPC Ink Recorder or desired circuit.

Section TV

Operation

When first installed the MRK-1 Relay should be checked by either of the following methods:

1. Connect an oscilloscope, $l^{\frac{1}{2}}$ volt dry cell battery, and a 10 ohm resistor to the Relay unit in accordance with the following diagram:



Put the power switches on the Relay unit, AHD, and the oscilloscope to the "ON" position, and allow a few minutes warm up time. Lower the tape feed roller on the Autohead, and set the speed for approximately 100 wpm. Turn the screwdriver adjustments Speed (R7) and Waveform (R9) to the extreme counter-clockwise position; then rotate the Speed control clockwise until the relay operates. Adjust the oscilloscope to obtain pattern. If the pattern is not an approximate square wave and the Autohead is known to be properly adjusted, correct by means of adjusting the Waveform control until a square wave pattern is obtained.

2. The Model MRK-1 Relay Unit may be adjusted by means of a TMC-Model RAPC Ink Recorder used in place of the oscilloscope, battery, and resistor. Prepare the recorder for operation; then connect the terminals of the Relay Unit to the "Ground" and "Contact" terminals of the Recorder by means of a suitable length of wire. The Relay unit may then be adjusted by observing the square wave pattern on the tape.

Section V

Parts List

Symbo	ol	Description	Function	TEC Part No.
Cla,	Clb	Capacitor, fixed: electrolytic; dual	Filter Condensers	CE52D2OCR
		unit, 20 mfd. ea. sect; 450 wvdc	TITUOT CONCONSCIS	OIJEDEOCI
C2a,	C2b	Capacitor, fixed: paper dual unit al mfd, +15%, ea. sect; 600 wvdc; oil filled and impregnated, hermetically sealed metal case.	Filter Condensers	СР69ВЦЕГ10Ц1
С3а,	СЗЪ	Capacitor, fixed: paper; dual unit d mfd, +15% ea. sect; 600 wvdc; oil filled and impregnated, hermetically sealed case	Time Constant	СР69ВЦЕГТОЦГ
E1		Board, terminal: general purpose barrier type; two terminals, 6-32 x 5/16 Binder Head Brass Nickel Plated Machine Screw	Output Terminals	TM-100-2
Fl Jl		Fuse, cartridge: 1 amp	Line Fuse	FU-100-1.0
		Connector, female contact: three contact shielded miniature type	Input from ADK	JJ-102-3
J2		Connector, male contact: two non- polarized blades	Power input	11-101
Kl Rl		Relay, sensitive: 3000 ohm coil Resistor, fixed: composition; 180 ohms,	Keying relay Filament drop-	RL-100 RC42GF181K
R2		#10%, 2 watts Resistor, fixed: composition; 180 ohms, #10%; 2 watts	ping resistor Filter resistor	RC42GF181K
R3		Resistor, fixed: composition; 180 ohms, \$10%; 2 watts	Filter resistor	RC42GF181K
RL		Resistor, fixed: wire wound; 5000 ohms, +10%; 5 watts	Voltage divider	RW-103
R5		Resistor, fixed: composition; 470 ohms,	Voltage divider	RC42CF181K
R6		Resistor, fixed: composition; 470 ohms, 410%; 2 watts	Voltage divider	RC42CF181K
R7		Resistor, variable: composition; 100,000 ohms, £10%; 1/2 watt: linear taper; 1/4" lg. x 1/4" rd. slotted shaft, with 3/8-32 x 3/8" lg. bushing	Speed Control	RV3A TSA 10LA
R8		Resistor, fixed: composition; 10,000 ohms, \$10%; 1/2 wett	Plate resistor	RC2OGF103K
R9		Resistor, variable: composition; 50,000 ohms, \$10%; 1/2 watt, linear taper; 1/4" lg. x 1/4" rd slotted shaft, with 3/8-32 x 3/8" lg. bushing	Waveform adjuster	RV3A TSA 503A
R10		Resistor, fixed: composition; 3.3 megohms, \$10%; 1/2 watt	Time Constant	RC20GF335K
Sl		Switch, toggle: SPST	Power On	ST12A
A.J		Tube, electron: 117NGT	Relay Control & Rectifier	117N7GT
X-1 X-2		Socket, tube; octal	Vl socket Cla, Clb socket	TS101P01 TS101P01

Symbol	Description	Function	TMC Part No.
X-3 W1	Socket, tube: 5 prong Cable Assembly: consists of two three contact male plug type con- nectors, interconnected by 10" three conductor cable	z socket	TS-100-1 CA-101
	Cable Assembly: power; consists of one non-polarized straight type molded female receptacie, 6 ft. cable, one male non-polarized plug		CA-102-1
XF1	Holder: fuse		FH-100-2

